


REINHOLD ENVIRONMENTAL Ltd.



## **2016 NO<sub>x</sub>-Combustion-CCR Round Table Presentation**

February 1 & 2, 2016, in Orlando, FL / Hosted by OUC

All presentations posted on this website are copyrighted by Reinhold Environmental, Ltd (RE). Any unauthorized downloading, attempts to modify or to incorporate into other presentations, link to other websites, or obtain copies for any other uses than the training of attendees to RE's Conferences is expressly prohibited, unless approved in writing by RE or the original presenter. RE does not assume any liability for the accuracy or contents of any materials contained in this library which were presented and/or created by persons who were not employees of RE.



**CORMETECH**



# SCR Catalyst Management for Optimal NO<sub>x</sub> and Hg Emissions Control

**Scott Rutherford**

**Chris Reeves**

Cormetech, Inc.

Reinhold Conference, 2016



---

# Presentation Outline



- **Catalyst Management**


- Overview
- Tools
- Case Study




# SCR Catalyst Functionality




## □ Reduce NOx



## □ Minimize undesirable side reaction



## □ Oxidize elemental Hg





# The SCR's Role in Hg Removal



Oxidize Hg for Downstream Capture!

- ① Elemental
- ② Oxidized
- ③ Particulate



Water solubility values (g/l) at ~20°C:  
 $\text{Hg} = 5.6 \times 10^{-5}$ ,  $\text{HgO} = 5.3 \times 10^{-2}$ ,  $\text{HgCl}_2 = 74$

**HgCl<sub>2</sub> removal**

# Key Differences for Hg vs. NOx

SCR is One Component of Overall System for Hg




- **DeNOx**

- SCR Performance Requirements are well defined due to the dominant role of the SCR for NOx reduction

- **Hg**

- Multiple systems may contribute to Hg control → SCR performance requirements are often not as well-defined yet may be essential for plant compliance




# Catalyst Design Considerations




## In Days Past:

Catalyst is formulated to achieve DeNOx requirements, while meeting SO<sub>2</sub> oxidation constraints.




## Today:

Catalyst is formulated to achieve DeNOx and Hg oxidation requirements, while meeting SO<sub>2</sub> oxidation constraints.



# Catalyst Design Considerations



# Hg Control

Site Specific. Includes All or Some Components.




## Coal Type and Combustion

- Hg Content
- Cl and Br Contents
- Added Cl and/or Br
- LOI in Fly Ash
- Boiler Load Profile

## Sorbents + ESP or FF

- ACI (+ DSI):
  - Hg Capacity
  - Temperature
  - SO<sub>3</sub> Concentration
  - HCl and HBr
  - Sorbent Injection Rate
  - DSI for SO<sub>3</sub> Mitigation
- Amended Silicates
- ESP or FF:
  - ACI, DSI Capture
  - Ash Capture (Hg on LOI)

**GOAL**  
**MATS Limit**  
**Hg ≤ 1.2 lbs/Tbtu**



## SCR Co-Benefits

- SCR:
  - Hg<sup>0</sup> Oxidation Activity
  - HCl and HBr
  - Temperature
  - Gas Composition
  - Seasonal Impacts
- WFGD:
  - Hg<sup>2+</sup> Net Capture Efficiency
  - Hg<sup>0</sup> Reemission

## APH

- Passive; small amount of Hg Oxidation

**Strategy:** Utilize all or some of these components to deliver a robust control plan for MATS compliance. Currently installed APCE can influence selection.

# Catalyst Management - Field



- **Inspection/Maintenance**
  - Catalyst
  - Ash Layout/Plugging
  - Ammonia Injection System
  - Ductwork
  - Expansion Joints
  - Cleaning Equipment
- **Performance**
  - Testing
  - NH<sub>3</sub> Balancing
- **Manage Potential**
  - DeNOx & Hg Oxidation



## DeNOx

$$\frac{K_{DeNOx}}{AV} = -\ln[1 - \eta_{DeNOx}]$$

$\eta_{DeNOx}$  = DeNOx efficiency

**$K$  = DeNOx Activity**

*Defined at MR=1.0*

*Independent of layer position*

## Hg Oxidation

$$\frac{K_{HgOx}}{AV} = -\ln[1 - \eta_{HgOx}]$$

$\eta_{HgOx}$  = fraction of  $Hg^0$  oxidation

**$K$  = Hg Oxidation Activity**


*Defined as simplified first order reaction*

*Highly dependent on conditions*


*Dependent on layer position ( $NH_3$  level)*

*Can change as layers above are replaced or deactivate*

# Breakdown of Design Potential





# Breakdown of Design Potential




# Presentation Outline

- **Catalyst Management**

- Overview
- **Tools**
- Case Study



# Catalyst Management Tools



# Measuring Catalyst Performance



- **Measure DeNOx**
  - Inlet and Outlet NOx: CEMS (Chemiluminescence)
  - NH<sub>3</sub> Slip: Wet Impinger/IC, FTIR
- **Measure SO<sub>2</sub> Oxidation**
  - SO<sub>2</sub>: CEMS (UV)
  - SO<sub>3</sub>: Controlled condensation
- **Lab-scale catalytic reactors**
  - Micro reactor
  - Bench reactor
- **Field (full scale reactor)**
  - SCR inlet and outlet NOx measurements
    - Operating condition changes & transients
    - Representative sampling
  - Stack NOx measurements
    - Final system performance

# Measuring Catalyst Performance



- **Measure Hg<sup>0</sup> and Hg<sup>2+</sup>**
  - CEMS
  - Sorbent traps
  - Ontario-Hydro
- **Lab-scale catalytic reactors**
  - Micro reactor
  - Bench reactor
- **Field (full scale reactor)**
  - SCR inlet and outlet measurements
    - Particulate challenge (high dust difficult to measure)
    - Operating condition changes & transients
    - Representative sampling
  - Stack measurements
    - Final system performance
    - SCR contribution combined

# Reactor Test Capabilities



## **Semi-Bench**

DeNox Activity(gas)  
High NO2  
DP  
CO Oxidation



## **Full Bench**

DeNox Activity (gas/coal)  
SO2 Oxidation  
DP  
Mercury Oxidation




## **Micro**

DeNox Activity (gas/coal)  
SO2 Oxidation  
Mercury Oxidation  
CO Oxidation  
High NO2



# Micro Reactor



- Example shown is fully-automated for efficient data collection.
  - Well suited for parametric studies
  - Can measure under a full range of conditions to develop catalysts and assist with management strategies.



# Bench Reactor



- **Bench is well-suited for field audit testing**
  - **Full size element (Full cross-section, Full length)**
    - Catalyst poisons not evenly distributed throughout log.
  - **Multi-layer system test**
    - System and individual layer performance in a single test
- Can test honeycomb, plate, corrugated (or any combination).
- Full range of flue gas conditions including HCl and HBr injection.



# Factors Impacting DeNOx and SO<sub>2</sub> Oxidation



Factor	DeNOx Correlation with Increasing Factor Value	Note
Temperature	↑	
O <sub>2</sub>	↑	
H <sub>2</sub> O	↓	
SO <sub>2</sub> /SO <sub>3</sub>	↑	
Catalyst V <sub>2</sub> O <sub>5</sub>	↑	SO2 to SO3 conversion limits formulation

Factor	SO <sub>2</sub> Oxidation Correlation with Increasing Factor Value	Note
Temperature	↑	
O <sub>2</sub>	↑	
Inlet SO <sub>3</sub>	↓	
NH <sub>3</sub>	↓	
Catalyst V <sub>2</sub> O <sub>5</sub>	↑	SO2 to SO3 conversion limits formulation

# Factor Impacting Hg Oxidation

## Positive Correlations













Factor	Hg Oxidation Correlation with Increasing Factor Value	Note
HCl	↑	Strong interdependence with T and concentration
HBr	↑	Strong interdependence with T and concentration
HI	↑	Strong interdependence with T and concentration
O <sub>2</sub>	↑	
Catalyst surface area	↑	Determined by layer length and Ap/pitch selection
Catalyst V <sub>2</sub> O <sub>5</sub>	↑	
Advanced catalysts	↑	Improve Hg ox at constant DeNOx and SO <sub>2</sub> ox
Hg <sup>0</sup>	○	No impact: kinetics are first order in Hg <sup>0</sup>

# Factor Impacting Hg Oxidation

## Negative Correlations



Factor	Hg Oxidation Correlation with Increasing Factor Value	Note
Hg <sup>2+</sup>		Impact depends on re-reduction activity
Temperature		Strong interdependence with HCl, HBr, NH <sub>3</sub> , catalyst
NH <sub>3</sub>		Strong interdependence with T, HCl, HBr, catalyst
NO		Impact is cross-correlated through NH <sub>3</sub>
H <sub>2</sub> O		
SO <sub>2</sub>		
SO <sub>3</sub>		
CO		Strong interdependence with T, HCl, HBr, catalyst
Hydrocarbons		
Catalyst Age		Strong interdependence with catalyst type

# SCR Hg Mass Balance



- **At the SCR inlet, Hg is present in three forms:**

$$\text{Hg}_{\text{in}}^{\text{total}} = \text{Hg}_{\text{in}}^0 + \text{Hg}_{\text{in}}^{2+} + \text{Hg}_{\text{in}}^{\text{particulate}}$$

*Particulate Hg is not affected by the SCR*

- **Hg mass balance across SCR (at steady state):**

$$\text{Hg}_{\text{in}}^0 + \text{Hg}_{\text{in}}^{2+} = \text{Hg}_{\text{out}}^0 + \text{Hg}_{\text{out}}^{2+} \quad 2\text{Hg} + 4\text{HCl} + \text{O}_2 \rightarrow 2\text{HgCl}_2 + 2\text{H}_2\text{O}$$

- **Quantify Hg oxidation by the SCR:**

$$\eta_{\text{HgOx}} = \frac{\text{Hg}_{\text{in}}^0 - \text{Hg}_{\text{out}}^0}{\text{Hg}_{\text{in}}^0}$$


$$\% \text{ Oxidized} = \frac{\text{Hg}_{\text{out}}^{2+}}{\text{Hg}_{\text{out}}^0 + \text{Hg}_{\text{out}}^{2+}}$$

# Impact of HCl and NH<sub>3</sub>

## Hg Oxidation Activity



The kinetic data are consistent with a mechanism where HCl adsorbs on the catalyst. NH<sub>3</sub> can significantly inhibit Hg oxidation activity.




400°C, 3.5% O<sub>2</sub>, 11% H<sub>2</sub>O, 350 ppm NO, 1000 ppm SO<sub>2</sub>, 10 ppm SO<sub>3</sub>, 100 ppm CO; MR = Inlet Molar Ratio

# Impact of HCl on NH<sub>3</sub> Inhibition



## Hg Oxidation Activity

There is a strong Interdependence between the HCl concentration and the degree of NH<sub>3</sub> suppression of the Hg oxidation rate.




400°C, 3.5% O<sub>2</sub>, 11% H<sub>2</sub>O, 350 ppm NO, 1000 ppm SO<sub>2</sub>, 10 ppm SO<sub>3</sub>, 100 ppm CO; MR = Inlet Molar Ratio

# Impact of Temperature (MR=0.2)



## Hg<sup>0</sup> Oxidation Activity

Listed activation energy values are for the overall Hg oxidation reaction. Values are negative because the rate decreases as temperature increases.




3.5% O<sub>2</sub>, 11% H<sub>2</sub>O, 350 ppm NO, 1000 ppm SO<sub>2</sub>, 10 ppm SO<sub>3</sub>, 100 ppm CO; MR = Inlet Molar Ratio

# Impact of Temperature (MR=0.9)



## Hg Oxidation Activity

With high inlet  $\text{NH}_3$ , the activation energy decreases for constant HCl, which indicates that  $\text{NH}_3$  inhibition can become more pronounced at high temperature.




3.5%  $\text{O}_2$ , 11%  $\text{H}_2\text{O}$ , 350 ppm  $\text{NO}$ , 1000 ppm  $\text{SO}_2$ , 10 ppm  $\text{SO}_3$ , 100 ppm  $\text{CO}$ ; MR = Inlet Molar Ratio

# Impact of Temperature

## Hg Oxidation Activity




Increasing HCl can reduce the amount of NH<sub>3</sub> suppression across the temperature range.



3.5% O<sub>2</sub>, 11% H<sub>2</sub>O, 350 ppm NO, 1000 ppm SO<sub>2</sub>, 10 ppm SO<sub>3</sub>, 100 ppm CO; MR = Inlet Molar Ratio


# Impact of Inlet $\text{Hg}^{2+}$



- Higher inlet  $\text{Hg}^{2+}$  reduces the  $\text{Hg}^0$  oxidation rate due to reverse reactions.
- Highest impact will be at high temperatures, in the presence of reducing agents ( $\text{NH}_3$ ,  $\text{CO}$ ,  $\text{SO}_2$ ), and lower  $\text{HCl}$
- Testing at low inlet  $\text{Hg}^{2+}$  relative to the field condition should give a conservative measurement of outlet  $\% \text{Hg}^{2+}$ .

- **Depending on your SCR Hg oxidation requirement traditional catalyst may be able to meet your needs.**
- **But, for challenging conditions, such as...**
  - Lower HCl, and/or
  - Higher temperature, and/or
  - Higher concentration of reducing agents (NH<sub>3</sub>, CO, SO<sub>2</sub>)
- **...we can modify catalyst formulation and processing to improve Hg oxidation relative to DeNOx and SO<sub>2</sub> oxidation**

# Advanced Catalyst: Low HCl



370°C, 250 ppm NO, 0.9 MR, 4% O<sub>2</sub>, 14% H<sub>2</sub>O, 400 ppm SO<sub>2</sub>, 4 ppm SO<sub>3</sub>, 100 ppm CO

# Advanced Catalyst: NH<sub>3</sub> Impact



**Advanced Catalyst also has a performance benefit in the First Layer position for higher HCl cases.**


Single Layer Performance Example					
Position	Case	MR	HCl [ppm]	Layer Hg Ox	Hg Ox Delta Advanced vs. Traditional
Layer 1	Traditional Catalyst	1.0	58	53%	
Layer 1	Advanced Catalyst	1.0	58	72%	18%

*371°C, 305 ppm NO, 1.0 MR, 4.3% O<sub>2</sub>, 8.5% H<sub>2</sub>O, 850 ppm SO<sub>2</sub>, 8 ppm SO<sub>3</sub>, 100 ppm CO.*

**COMET™ catalyst can significantly improve Hg oxidation in the upper layers of the SCR**

# Catalyst Deactivation

## Correlation with DeNOx Deactivation




*Hg oxidation deactivation generally correlates with DeNOx deactivation.*

*The extent of deactivation for the two reactions may not be equivalent:*

*K/Ko (Hg Ox) is sensitive to operating conditions (especially NH<sub>3</sub>, HCl, temperature, and catalyst type).*

# Advanced Catalyst: K/Ko



*400°C, 350 ppm NO, 0.9 MR, 3.5% O<sub>2</sub>, 12% H<sub>2</sub>O, 1000 ppm SO<sub>2</sub>, 10 ppm SO<sub>3</sub>, 100 ppm CO, 56 ppm HCl*

# Advanced Catalyst Deactivation




- Arsenic and Alkali poisoning
  - Hg Oxidation deactivation resistance is higher for COMET™ catalyst
  - Difference in deactivation rate is greatest at higher ammonia levels

*Hg Oxidation K/K0 vs. Arsenic level*



Arsenic concentration on catalyst surface / wt.%

*Hg Oxidation K/K0 vs. Alkali*





Added alkaline concentration on catalyst surface / wt.%

*Test condition: 400C, 3.5%O2, 12% H2O, 350ppmvd NOx, 1000ppmvd SO2, 100ppmvd CO, 56ppmvd HCl, MR = 0.9.*

# Presentation Outline

- **Catalyst Management**

- Overview
- Tools
- **Case Study**




- **Case Study**

- 2+1 design
- SCR is at 70,000 hours operation: time for an action
- What options to consider?


# Case Study 1

w/ DeNOx Potential & Hg Oxidation




# Case Study 1

w/ DeNOx Potential & Hg Oxidation




# Case Study 1

w/ DeNOx Potential & Hg Oxidation



# Case Study 1

w/ DeNOx Potential & Hg Oxidation



Target 90% Ox Hg EOL.  
Action: Initially change 2 layers to Max length COMET™ and inject Halogen

# Summary



- **Catalyst management for Hg oxidation and DeNOx are interdependent.**
- **SCR Hg oxidation is influenced by multiple factors**
  - Layer dependency
  - More factors in setting design conditions
  - Interdependencies between factors
  - Impacts of catalyst type & formulation
- **Cormetech has and integrated approach to optimize the SCR for Hg oxidation, maintain NOx reduction and manage SO<sub>2</sub> oxidation.**
  - Predictive modeling
  - Lab testing
  - Field experience
  - Product solutions



# CORMETECH



Thank You!

Questions?

---