

REINHOLD ENVIRONMENTAL Ltd.



2011 NO_x-Combustion Round Table & Expo Presentation

February 7-8, 2011, in Birmingham, AL / Hosted by Southern Company

All presentations posted on this website are copyrighted by Reinhold Environmental, Ltd (RE). Any unauthorized downloading, attempts to modify or to incorporate into other presentations, link to other websites, or obtain copies for any other uses than the training of attendees to RE's Conferences is expressly prohibited, unless approved in writing by RE or the original presenter. RE does not assume any liability for the accuracy or contents of any materials contained in this library which were presented and/or created by persons who were not employees of RE.



2011 NOX-Combustibles Roundtable

In Situ NO_x for Ammonia Injection Grid Control Improvements

HORIBA

Explore the future


8 February 2011

Harold Henry

Introduction

In-situ NO_x/O₂ analyzer for improved SCR process monitoring and control:


- Rapid control capability
- Lower life cycle costs
- Simple installation and operation



Instrument Development History



Automotive



Plant prototype



INM-700 product

Versatile Zirconium Oxide

- Porosity to oxygen ions at high temperatures (~650 C)


- Electrochemistry enables:

O₂ sensor

- Partial pressure differential
- Ions migrate to restore equilibrium
- Results in current flow

O₂ pump

- Applied current drives redox reaction
- Results in partial pressure differential



NO_x Sensor


2nd Chamber:

O₂ removed < 0.01 ppm

NO → ½ N₂ + ½ O₂

NO₂ → ½ N₂ + O₂

O₂ measured



1st Chamber:

O₂ removed < 10 ppm

CO + ½ O₂ → CO₂

H₂ + ½ O₂ → H₂O

NO, NO₂, N₂, CO₂, and

H₂O to 2nd chamber






Outline

- NO_x control using SCRs
- Need for spatially resolved, real time monitoring and control of NO_x
- Approach
- Results to date
- Next steps

NO_x Sources

1. Thermal formation



2. Combustion of fuels containing nitrogen

- bound within molecular structure


3. Prompt formation

- N₂ reaction with free radicals (OH, HCO, CH₃...)

Regulations require monitoring & control


Selective Catalytic Reduction (SCR)

- Reduction of NO_x by catalytic reaction with NH_3 to produce N_2 and H_2O
- Components
 - Ammonia injection grid (AIG)
 - Reactor chamber
 - Catalyst bed




Excess NH_3 called ammonia slip

Typical SCR Design




Catalyst Bed



Ammonia injection grid

Airheater Inlet Planes



Ammonia Slip Issues

- Formation of ammonium salts on air preheater and other downstream surfaces



Ammonium bisulfate
on preheater

- Ammonium chloride plume from the stack and gaseous ammonia emissions
- Ammonia odor in fly ash
- Costs of ammonia reagent

Process Control

■ Fundamentals

- It starts with the Analysis
- Requirements?
 - Specific
 - Timely
 - Appropriate
 - Maintainable

■ SCR Control

- Problem : NO_x based upon NH_3 addition
- Solution : Appropriate NO_x monitor

SCR Control - Analysis

- Extractive NO_x
 - Sample transport time
 - Expensive installation – probe + heated sample line
 - Expensive maintenance – CLA
- In-situ NO_x
 - Instantaneous measurement
 - Flange-mounted installation
 - Minimal maintenance

SCR Control – Control scheme

■ Feed-forward

- Before the catalyst
- Direct correlation NO_x vs NH_3
- Variable is incoming NO_x

■ Feed-back


- After catalyst
- Function of NO_x / NH_3 reaction
- Trims Feed-forward flow setting

Monitoring Catalyst Performance


- Catalyst maintenance – periodic sampling, cleaning
- Catalyst management – when to replace or refurbish, planned outages
- Maintain good ammonia distribution through tuning

SCR Performance Non-uniformity



NOx Reference




1 Year Later



Typical SCR Design




Catalyst Bed



Ammonia injection grid


Airheater Inlet Planes



Probe Locations




Outlet for trim



Inlet for feed forward




System Response Comparison




In situ is ~40 sec faster in this example*

*waste incinerator, Japan

SCR Inlet & Outlet Data




Tracking Recent Upset Event




Dust Analysis: x-ray fluorescence (XRF)



O, Al, Si; 200 μm




C; 300 μm




No ammonium bisulfate

Post Test Sensor Analysis: XRF

New Sensor



Sensor from Unit 6



No signs of poisoning or contamination

Summary

- New approach to NO_x developed, tested, and manufactured
 - Additional feature of simultaneous O₂
- In situ, low cost, low maintenance
- Integrated on coal plant SCR applications
- Demonstrated
 - High stability, accuracy, and responsiveness
- Next steps
 - Quantify cross sensitivity
 - Set up for active control





Thank you

