

Reinhold Environmental Ltd.



2010 NO_x-Combustion Round Table & Expo Presentation

February 8 & 9, 2010

Chattanooga, TN

All presentations posted on this website are copyrighted by Reinhold Environmental, Ltd (RE). Any unauthorized downloading, attempts to modify or to incorporate into other presentations, link to other websites, or obtain copies for any other uses than the training of attendees to RE's Conferences is expressly prohibited, unless approved in writing by RE or the original presenter. RE does not assume any liability for the accuracy or contents of any materials contained in this library which were presented and/or created by persons who were not employees of RE.



Measurement of Condensable Species in Flue Gas Streams

Richard McMillan
URS
Corporation

Introduction

- Condensables:
 - From an environmental perspective: stack emissions that condense in the flue gas stream exiting the stack or downstream of the stack – includes aerosols (sulfuric acid) and VOCs
 - Plant operations/engineering perspective: a substance that condenses in the flue gas stream anywhere in the unit, some of which are directly or indirectly related to NO_x reduction systems – includes sulfuric acid, ammonium salts, arsenic, and soot

Presentation Outline

The following aspects of condensable materials will be discussed:

- Where do condensable materials originate?
- Why you want to measure concentrations of condensables?
- How do you measure flue gas condensables?
- Measurement techniques discussed are “manual methods” – can be used for engineering data collection, performance guarantee tests, etc.
- Some continuous analyzers available – not included in this discussion

Origins of Condensables


- Sulfuric acid
- Soot
- Arsenic
- Ammonium salts

Origin of Condensable Material


NO_x, SO₃,
Arsenic
& Soot

NH₃

SO₃ & NH₃



Effect of SCR Conversion on Air Heater Inlet SO_3 Concentration*




*Assumes 1% boiler conversion of SO_2

Why do you need to know?

What you don't know can hurt you.

- Impacts of condensables on equipment
- If you need a mitigation system, knowing the flue gas properties assists in designing the system
- Some condensable materials are formed in the combustion process and the quantities formed can be a function of fuel properties and how a fuel is burned
- Equipment Performance Issues:
 - SO₂ oxidation across SCR catalyst: is SO₂ oxidation expectation being met?
 - Ammonia
 - How much vapor phase Arsenic is in flue gas entering SCR?
 - Is there a plume opacity issue? If so, what are contributing factors?

Consequences of Condensables in Flue Gas Stream




Sulfuric Acid

- As flue gas temperature drops below 800°F, SO_3 combines with H_2O and forms H_2SO_4 . This conversion is essentially complete when flue gas exits the air heater (~300°F)

Conversion of SO_3 to H_2SO_4

(Courtesy EPRI)




Sulfuric Acid

- Depending on the concentration, the H_2SO_4 dew point can range from 235°F to 310°F

Sulfuric Acid Dew Point


Effect of SO₃ on Sulfuric Acid Dew Point



Corrosion from Sulfuric Acid

- Lungstrom air heaters have cold spots that are below acid dew point
- H_2SO_4 condensation causes corrosion, and creates wet spots where ash/carbon can collect
- H_2SO_4 can become re-entrained in primary & secondary air streams
- Primary air containing H_2SO_4 can cause corrosion & pluggage where air enters pulverizer
- Corrosion of duct, ESP, etc. downstream of AH


Air Heater




Other Effects of SO₃

- Hg removal hindered
- Contributes to plume opacity
- Air heater pluggage

Impact on Hg Capture in Ash



Ammonium Sulfate/Bisulfate



Plume Opacity

- Visible plume opacity downstream of stack
- Normally caused by sub-micron particles (most severe in 0.8 μm size \sim wavelength of visible light)
- Visible plume opacity can be $> 80\%$ for high sulfur fuels

Plume Opacity Contributing Species


- Sulfuric acid
 - Sub-micron aerosol $<0.1 \mu\text{m}$ to $>0.8 \mu\text{m}$
 - H_2SO_4 hygroscopic – gets larger as it hydrates
 - White plume with blue tint – gets more severe w/hydration
 - Visible plume evident with as little as 5 ppm H_2SO_4
- Soot
 - Sub-micron particle $\sim 0.2 \mu\text{m}$ to $0.8 \mu\text{m}$
 - Gray-black plume
- Metal oxides (ash, scrubber carryover)
 - White-gray plume

Fate of $\text{SO}_3/\text{H}_2\text{SO}_4$


Existing air emission controls do not collect SO_3 /sulfuric acid at high efficiency:

- 10-20% removal typical across air heaters and cold-side ESPs
 - Mostly adsorption, condensation
 - Actual percentages vary significantly
- Widely varied removal across wet scrubbers
 - Measured range <10% to >80%

Predicted Effects of SO₃ on Plume Opacity*



*25-ft stack diameter



Without SO₃ mitigation

with SO₃ mitigation

7 10:39 AM

Measurement Techniques to Determine Condensable Levels in Flue Gas

- $\text{SO}_3/\text{H}_2\text{SO}_4$
- Ammonia
- Arsenic
- Soot

Sampling System Components Common to Most Methods

- Probe
- Condenser Train (impingers) – determine flue gas moisture (engineering data & sanity check)
- Pump
- Dry Gas Meter
- O₂ at DGM exit recommended


SO₃ Measurement

- EPA Method 8 – not appropriate for flue gas streams with high moisture – ASTM committee working on method based on Controlled Condensation
- FTIR
 - Expensive
 - Can be difficult to operate
- Controlled Condensation System (CCS)
 - Preferred method
 - Single point, non-iso-kinetic sampling
 - Several variations (CTM-013/M-8A – Kraft Recovery Furnaces)
- Cascade Impactor (wet/cold stack)
- Analysis of samples by Titration or IC

CCS Equipment

- Heated quartz or glass lined probe
- Thimble filter in oven
- Modified Graham condenser coil
- Circulating hot water bath (maintain coil temperature $\sim 20^{\circ}\text{F}$ > moisture dew point)
- Transfer tube from coil to impinger train
- Moisture condenser containing DI or hydrogen peroxide
- Meter box & pump

CCS Train Schematic




CCS Equipment



CCS Pre-Test Procedures

- Use equipment arrangement that allows coil to be observed during operation (some methods have heat blanket covering coil)
- Modified sampling procedures might be required for certain situations (wet stacks, sorbents/reactive solids bias: high alkali ash, trona, lime, SBS – might require inertial gas separator)
- Conduct pre-test leak check (glass-to-glass connections in CCS oven make this challenging – unable to use Teflon^r tape because of high temperature)

Inertial Gas Separator



CCS Pre-Test Procedures

- Establish probe and filter temperatures at approximately 550°F or hotter, depending on sampling location (prevents condensation of H₂SO₄/formation of ammonium salts)
- Circulating water bath temperature should be approximately 170°F (depends on conditions)
- Record initial dry gas meter reading

CCS Sampling Procedures

- Establish and maintain sampling rate at ~0.3 cfm (some conditions require other rates)
- Maintain probe and oven temps. ~550°F +
- Maintain modified Graham condenser coil exit temperature at approximately 20°F – 25°F above moisture dew point (~150°F – 160°F)
- Collect sample for 25 to 60 minutes
 - depends on concentration of SO₃
 - observation of sulfuric acid collection in coil
- Measure flue gas sample O₂
- Observe coil
 - Sulfuric acid appears as “frosting” on coil, white deposit (ammonium salts), large drop (high SO₃ concentration)

CCS Sample Recovery Procedures

- At completion of sampling, stop pump, record final meter volume
- Stop hot water circulating pump
- Remove coil, filter end first
- Rinse coil with DI water
- Replace with new coil
- Repeat sampling procedure (3 times)
- Analyze recovered sample for sulfate using titration or IC

Ammonia Sampling


- FTIR
 - Expensive
 - Can be difficult to operate
- EPA CTM-027
 - Standard method: iso-kinetic with EPA Method 17 in flue duct filter (iso-kinetic not necessary for vapor phase sampling upstream of air heater)
 - Initially developed for stack measurements
 - If SO_3 present, much of ammonia is collected as ammonium salts in transfer tubing
 - Impinger train containing 0.1 N H_2SO_4 collects vapor phase NH_3
 - Modified method (external filter @ 248°F +/-25°F) could be used to determine “free” ammonia (downstream of AH)
 - Altering method might be necessary depending on the purpose of measurement
- Analysis of samples by Ion Selective Electrode or IC

Ammonia Sampling Equipment

- Heated quartz or glass lined probe
- Filter at tip of probe inside flue (standard) or outside flue in oven (modified)
- Teflon transfer tube
- Moisture condenser containing 0.1 N H₂SO₄
- Meter box & pump

CTM-027 – “Standard” Non-isokinetic Method w/In-Flue Filter

Glass bell with quartz fiber filter material



Ammonia Sampling Procedures

- Conduct pre-test leak check
- Heat probe to approximate temperature of flue gas
- Record initial dry gas meter reading
- Collect sample from single point or multiple points (traverse) for 1 to 2 hours (sampling time depends on sensitivity desired), rate ~ 1 cfm
- Measure O₂ at meter exit (recommended)
- Record final dry gas meter reading
- If SO₃ is present in flue gas, some/all ammonia will collect in transfer tube as ammonium salts (visible to observer)

Ammonia Sample Recovery

- After probe cools, rinse probe, transfer tubing and combine with contents of impingers containing 0.1 N H₂SO₄
- Analyze sample for ammonia: ion specific electrode (ISE) or ion chromatography


SO₃, Ammonia (ABS)

- FTIR (expensive, difficult to operate)
- Breen probe
 - Modified acid dew point probe
 - In-situ, single point, batch analysis
 - Ammonia Slip (as ABS)
 - SO₃ (condenses H₂SO₄ on probe tip)
 - Indicates relative levels of ABS/SO₃
 - Should be calibrated against test methods that yield known results

Arsenic

- EPA Method 29 – Metals Train, uses external filter at 248°F +/- 25°F
- Can modify approach to incorporate in flue filter in order to segregate vapor & solid phase Arsenic (measurements taken up-stream of SCR); might require use of IGS
- For determination of As only, M-29 impinger train is modified to eliminate impingers 4 – 6

Standard EPA Method 29



Method 29 Procedures

- Iso-kinetic sampling method
- Initial leak check
- Record initial dry gas meter reading
- Sample iso-kinetically for 1-hour while traversing flue (single point sample optional, non-iso-K optional – depends on whether total As or vapor phase As is to be determined)
- Measure sample O₂
- Record final dry gas meter reading

Method 29 Recovery & Analysis

- Rinse nozzle, probe, filter housing (“front-end” sample)
- Recover filter (“front-end” sample)
- Recover impingers 1 – 3 (“back-end” sample)
- Analyze samples using inductively coupled argon plasma emission spectroscopy (ICAP) or atomic absorption spectroscopy (AAS)
- “Front-end” yields solid/liquid phase As
- “Back-end” yields vapor phase As


Stack Measurements: Plume Opacity Analysis or Engineering Data

- Sulfuric acid
 - CCS (operate at elevated temperature)
 - Cascade impactor
- Soot
 - Cascade impactor
- Metal oxides (ash, scrubber carryover)
 - Cascade impactor
- PM mass loading
 - M-17


Cascade Impactor

- U of Washington Mark V
 - 12 stages
 - 0.15 μm to 10 μm
 - Single point sample, point of average velocity in stack
 - Quartz substrates
 - Gravimetric analysis
 - Carbon (soot) analysis by stage
 - Kapton (plastic)
 - Metals analysis by PIXE by stage
 - Sulfate (H_2SO_4) analysis by IC by stage

U of Washington Mk V Cascade Impactor




U of W Mark V Cascade Impactor



U of W Cascade Impactor



U of W Mark V Cascade Impactor Quartz Substrates



Concluding Comments

- Use the appropriate adaptation of the sampling method for the particular application/sampling condition
 - Hot flue gas stream (upstream of AH)
 - Cool flue gas stream (downstream of AH)
 - Interference from reactive components (use of IGS) – can significantly bias results
 - Wet stack
- Observe sample collection
 - CCS coil
 - Ammonia sample transfer tube
 - DGM exit O₂
 - Sampling system data – temperatures, pressures, flow
- Since most of these measurements are for “Engineering Data” – can “bend the rules” to adapt a sampling system to collect the information desired