


REINHOLD ENVIRONMENTAL Ltd.



2019 NO_x-Combustion-CCR Round Table Presentation

February 11 & 12, 2019, in Salt Lake City, Utah / Hosted by PacifiCorp

All presentations posted on this website are copyrighted by Reinhold Environmental, Ltd (RE). Any unauthorized downloading, attempts to modify or to incorporate into other presentations, link to other websites, or obtain copies for any other uses than the training of attendees to RE's Conferences is expressly prohibited, unless approved in writing by RE or the original presenter. RE does not assume any liability for the accuracy or contents of any materials contained in this library which were presented and/or created by persons who were not employees of RE.



Honeycomb type catalyst



Plate type catalyst



Corrugated type catalyst

SCR Catalyst Laboratory Testing: Results of EPRI's Round Robin Study & Revised Laboratory Testing Protocol

W. Scott Hinton, Ph.D., P.E.

W.S. HINTON & ASSOCIATES
1612 Smugglers Cove Circle, Gul Breeze, FL 32563
Tel: 850-261-5239
email: shinton@wshinton.com

EPRI Project Mangers

Tom Martz
Alex Jimenez

Primary EPRI Studies - DeNOx

Bench Scale Testing for DeNOx and SO2 Conversion

Multi-Laboratory Comparative SCR Catalyst Testing for DeNOx Activity and SO2 Conversion: 2017 Testing Results (Round Robin Testing)

- Product Id: 3002010384
- Date Published: Feb 14, 2018

Laboratory Testing Protocol for Coal-Fired SCR Catalyst: 3rd Edition


- Product Id: 3002013048
- Date Published: Nov 14, 2018

Round-Robin Testing Highlights




- 7 Bench-scale labs participated
- Tested 4 samples total, 2 each of identical honeycomb and plate
- Full length honeycomb (1,152 mm), Full length plate (single plate - 623mm)
- “Round-robin” approach, initiating lab re-tested at end of cycle

Plate Catalyst Activity Test Results




Parameter	Plate
DeNOx	75.4%
Average Activity	46.3 m/hr
Average Absolute Deviation	±3.66 m/hr
Average Relative Deviation	±7.92%
Average Absolute Standard Deviation	2.69 m/hr
Average Relative Standard Deviation	5.8%

Honeycomb Catalyst Activity Test Results




Parameter	Honeycomb
DeNOx	91.0%
Average Activity	35.1 m/hr
Average Absolute Deviation	±1.37 m/hr
Average Relative Deviation	±3.90%
Average Absolute Standard Deviation	1.03 m/hr
Average Relative Standard Deviation	2.9%

Activity Test Results Summary




Parameter	Plate	Honeycomb
DeNOx	75.4%	91.0%
Average Activity	46.3 m/hr	35.1 m/hr
Average Absolute Deviation	±3.66 m/hr	±1.37 m/hr
Average Relative Deviation	±7.92%	±3.90%
Average Absolute Standard Deviation	2.69 m/hr	1.03 m/hr
Average Relative Standard Deviation	5.8%	2.9%

Plate Catalyst SO₂ Conversion Test Results




Parameter	Plate
Average SO ₂ Conversion	0.20%
Average Absolute Deviation	±0.12%
Average Relative Deviation	±56.78%
Average Absolute Standard Deviation	0.07%
Average Relative Standard Deviation	34%

Honeycomb Catalyst SO₂ Conversion Test Results



Parameter	Honeycomb
Average SO ₂ Conversion	0.28%
Average Absolute Deviation	±0.06%
Average Relative Deviation	±21.20%
Average Absolute Standard Deviation	0.04%
Average Relative Standard Deviation	16%

SO₂ Conversion Test Results Summary



Parameter	Plate	Honeycomb
Average SO ₂ Conversion	0.20%	0.28%
Average Absolute Deviation	±0.12%	±0.06%
Average Relative Deviation	±56.78%	±21.20%
Average Absolute Standard Deviation	0.07%	0.04%
Average Relative Standard Deviation	34%	16%

Revised Protocol Highlights

- 10 years since last protocol was issued: time to update to ensure consistency with current practice and best available test methods
- Expansion of the scope to include semi-bench facilities
- Adjustments to the required target and maximum drift accuracy of test conditions for both activity and SO₂ oxidation measurements
- Addition of detailed test sample assembly procedures for plate-type catalysts
- Detailed discussions related to the setting of the NH₃/NO_x ratio, including general approaches
- Error analyses for both deNO_x and SO₂ oxidation measurements
- Reporting templates for deNO_x activity and SO₂ oxidation measurement data.

Activity Test Conditions

Table 3-2
Activity Test Conditions

Parameter	Target	Allowed Deviation from Target	Required Measurement Accuracy	Maximum Drift During Testing
Temperature	Representative field condition	± 5 °F (± 2.8 °C)	± 3 °F (± 1.7 °C)	± 5 °F (± 2.8 °C)
Linear Velocity	Representative field condition	$\pm 10\%$	$\pm 2\%$ of value	$\pm 5\%$ of value
O ₂	Representative field condition	$\pm 0.2\%$ absolute	$\pm 0.1\%$ absolute	$\pm 0.1\%$ absolute
H ₂ O	Representative field condition or as-generated	NA	$\pm 1\%$ absolute	$\pm 1\%$ absolute
CO ₂	As-generated	NA	NA	NA
NO _x (inlet)	Representative field condition	$\pm 10\%$	$\pm 1\%$ of value	$\pm 1\%$ of value
NO _x (outlet)	NA	NA	$\pm 1\%$ of value	NA ²⁵
SO ₂	Representative field condition	$\pm 1\%$	$\pm 1\%$ of value	$\pm 0.5\%$ of value
SO ₃	None added	NA	NA	NA
NH ₃ /NO _x ratio	1.01	± 0.01 absolute	± 0.01 absolute	± 0.01 absolute
N ₂	Balance	NA	NA	NA

SO₂ Conversion Test Conditions

Table 4-2
SO₂ Oxidation Test Conditions

Parameter	Target	Allowed Deviation from Target	Required Measurement Accuracy	Maximum Drift During Testing
Temperature	Representative field condition	± 5 °F (± 2.8 °C)	± 3 °F (± 1.7 °C)	5 °F (± 2.8 °C)
Linear Velocity [§]	Representative field condition	± 10%	± 2% of value	± 5% of value
O ₂	Representative field condition	± 0.2% absolute	± 0.1% absolute	± 0.1% absolute
H ₂ O	Representative field condition or as-generated	NA	± 1% absolute	± 1% absolute
CO ₂	As-generated	NA	NA	NA
NO _x Inlet	Representative field condition	± 10%	± 1% of value	± 1% of value
SO ₂	Representative field condition	± 1%	± 1% of value	± 0.5% of value
SO ₃ Inlet	None added	NA	± 0.2 ppmv	± 0.2 ppmv
SO ₃ Outlet	NA	NA	± 0.2 ppmv	± 0.2 ppmv
NH ₃ /NO _x ratio	0	NA	NA	NA
N ₂	Balance	NA	NA	NA

Hypothetical True Values for Error Analyses

Table A-1

Hypothetical Test Samples – True Values for Test Conditions and Results

Parameter	Honeycomb	Plate
Sample Length (mm)	1,000	500
Pitch (mm)	7.10	
Wall Thickness (mm)	0.71	
Geometry	Cell Opening: 6.39 mm	Plate Width: 150 mm
Sample Cross-Section (mm x mm)	150 x 150	
LV (m/s at actual temp, 1 atm.)	6.00	
AV (m/hr)	18.0	36.0
NH ₃ /NO _x Ratio	1.01 (activity) 0.0 (SO ₂ oxidation)	
deNO _x	89.16%	67.08%
Activity (m/s)	40.0	
SO ₂ Oxidation (% , full layer)	0.35	
Inlet NO _x (ppmvd at actual O ₂)	250.0	
Outlet NO _x (ppmvd at actual O ₂)	27.1	82.3
Inlet SO ₃ (ppmvd at actual O ₂)	3.0	
Outlet SO ₃ (ppmvd at actual O ₂)	6.50	4.75
O ₂ (% , dry)	3.4	
H ₂ O (% , actual O ₂)	10.0	
SO ₂ (ppmvd at actual O ₂)	1,000	
CO ₂ /N ₂	balance	

Activity Cumulative Errors

Table B-12
Expected Maximum Deviations in Activity Determinations Based on **Deviation Limits** of Test Parameters

Parameter	Allowed Deviation from Target	Expected Maximum Relative Deviation in Measured K	
		HC	Plate
Temperature	± 5°F (±1.7°C)	±1.50%	±1.50%
Linear Velocity	± 10%	±0.80%	±1.20%
O ₂	± 0.2% absolute	±1.00%	±1.00%
H ₂ O	NA	NA	NA
NH ₃ /NO _x ratio	±0.01 absolute	±0.60%	±0.60%
Global Deviation		±2.1%	±2.2%

Table B-13
Expected Maximum Errors in Activity Determinations Based on Required Measurement **Accuracy** of Test Parameters

Parameter	Required Measurement Accuracy	Expected Maximum Relative Error in Measured K	
		HC	Plate
Temperature	± 3°F (±1.7°C)	±0.90%	±0.90%
Linear Velocity	± 2% of value	±2.00%	±2.00%
O ₂	± 0.1% absolute	±0.50%	±0.50%
H ₂ O	± 1% absolute	±0.70%	±0.70%
Inlet NO _x	± 1% of value	±0.45%	±0.90%
Outlet NO _x	± 1% of value	±0.45%	±0.90%
NH ₃ /NO _x ratio	±0.01 absolute	±0.60%	±0.60%
Geometry ⁶⁴	Length: ±1 mm Plate Width (plate cat.): ±1 mm Channel Width (HC cat.): ±0.01 mm	±0.26%	±0.87%
Global Error		±2.5%	±2.9%

-Total cumulative potential deviation/error in measured K-values from the true value at the target conditions will be about 4-5%. This corresponds to a total absolute deviation/error of about ±1 m/hr for low activity catalysts (20 m/hr), and about ±2 m/hr for high activity catalysts (40 m/hr).

-If corrections are applied to all pertinent parameters, the deviation/error in the activity measurement can be effectively halved.

-Note that these total deviation/error values do not include the potential effect of SO₃.

SO₂ Conversion Cumulative Errors

Table G-6
Expected Maximum Deviations in SO₂ Oxidation Determinations Based on **Deviation Limits** of Test Parameters

Parameter	Allowed Deviation from Target	Expected Maximum Relative Deviation in Measured SO ₂ Oxidation	
		HC	Plate
Temperature	± 5°F (±1.7°C)	±5.6%	±5.6%
Linear Velocity ⁹⁴	± 10% of value	±10%	±10%
O ₂	± 0.2% absolute	±1.5%	±1.5%
SO ₂	± 1% of value	±1.0%	±1.0%
Total Deviation		±11.6%	±11.6%

Table G-7
Expected Maximum Errors in SO₂ Oxidation Determinations Based on Required **Measurement Accuracy** of Test Parameters

Parameter	Required Measurement Accuracy	Expected Maximum Relative Error in Measured SO ₂ Oxidation	
		HC	Plate
Temperature	± 3°F (±1.7°C)	±3.4%	±3.4%
Linear Velocity	± 2% of value	±2.0%	±2.0%
O ₂	± 0.1% absolute	±0.8%	±0.8%
SO ₂	± 1% of value	±1.0%	±1.0%
Inlet SO ₃	± 0.2 ppmv	±5.7%	±11.4%
Outlet SO ₃	± 0.2 ppmv	±5.7%	±11.4%
Total Error		±9.0%	±16.6%

-Total cumulative potential deviation/error in measured SO₂ oxidation = 20% for honeycomb samples and about 27% for plate samples (relative).

-This corresponds to a total absolute deviation/error of about 0.07% for the honeycomb test sample and about 0.10% for the example plate test sample (absolute).

-Errors associated with deviations in test conditions can be reduced somewhat by applying correction curves, but this is limited to applicability of curves.

-Note that the error analyses do not include the effect of SO₃.

Appendix C: Plate Stacking Guidelines



Example element box with 26 coupons – alternating between coupons with 2 notches and coupons with 1 notch. Coupons were cut from full-size plates containing 4 notches.

- Primary Goal: Match field configuration as closely as possible
- Number of beads and bead direction can hinder replicating field configuration
- Surface area calculation approach should be consistent between field total surface area (AV) calculations and the lab basis when applying lab K-values directly for field potential calculations (i.e. how are notches accounted for in the lab and the field calculations?).
- More work needs to be done!



Down to the right notch



Down to the left notch

Using Lab Data for Catalyst Management

- Catalyst management plans typically work off of field potential (P) for the entire reactor.
- An accurate estimate of field potential requires a number of inputs, including;
 - Catalyst K-values (absolute) over time; initial activity and a deactivation rate prediction (curve) are required.
 - Accurate catalyst total surface area (K-values from the lab must correspond to the same surface area basis as that used in the field).
 - Estimate of fouling/plugging
- Re-Baselining the unit to get appropriate flow rates, temperatures, and NOx reductions is important – using design conditions will create errors in almost all cases, very large errors in some cases.
- Laboratory K-values should be generated at the correct corresponding field representative full load conditions. If not, correction curves should be applied.
- Don't change catalyst test conditions mid-stream. Do update test conditions to actual when new catalyst is installed.

Primary EPRI Studies - Mercury

Mercury Oxidation at Semi-Bench and Micro Scale

Laboratory Comparative SCR Catalyst Testing for Mercury Oxidation: 2017 Testing Results

- Product Id: 3002011761
- Date Published: Dec 04, 2018

SCR Catalyst Mercury Oxidation Laboratory Testing Guideline – Industry Version

- Product Id: 3002005087
- Date Published: Mar 03, 2015



W. Scott Hinton, Ph.D., P.E.

W.S. HINTON & ASSOCIATES

1612 Smugglers Cove Circle

Gulf Breeze, FL 32563

Cell: 850-261-5239

email: shinton@wshinton.com

