

REINHOLD ENVIRONMENTAL[®]



2024 Reinhold/PCUG Round Table Presentation

Hosted by LG&E/KU and Co-hosted by Southern Co. and TVA
in The Marriott Resort Lexington Griffin Gate Hotel, Lexington,
KY on June 24-25, 2024

All presentations posted on this website are copyrighted by **REINHOLD ENVIRONMENTAL[®]** (RE). Any unauthorized attempts to print, to download, to modify, to incorporate into other presentations, to link to other websites or to obtain copies for any other uses than the training of attendees to RE Conferences is expressly prohibited unless approved in writing by RE or the original presenter. RE does not assume any liability for the accuracy or contents of any materials in this library which were presented and/or created by persons who were not employees or subcontractors of RE.

Methods of SCR/CO Catalyst Testing

Their Role in SCR Performance Investigations



Presented at:



June 24, 2024

Presented By:



Dan Ott

Environex, Inc.

Malvern, PA 19355

(484) 320-8608

Environex.com



Environex, Inc

Who We Are

- Industry consultants for the last 30+ years with SCR and Oxidation Catalyst Systems
- We specialize in SCR of all types of: Technologies, Systems, Catalyst, Fuel Types (Coal, Gas, Oil, MSW...)

What We Do


- SCR/CO Lifecycle Management
- Catalyst Testing
- SCR/CO Design Services
- AIG Tuning
- Consulting/Troubleshooting/ROI
- Training




SCR Systems – Coal vs Natural Gas Applications

Variable/Parameter	Coal	Gas
Catalyst Volume	High/3 to 6 Layers	Low/1 or 2 Layers
Ammonia Injection	Further Upstream	Directly in front of catalyst
Ammonia Source	Anhydrous or Urea	Aqueous Ammonia
Dust	High Dust/Sandstorm	Minimal (but very fine)
NOx Removal Needed	Medium (60 to 90%)	High (70 to 95%)
Ammonia Slip	Less Important	Very Important
SO ₂ to SO ₃ Oxidation	Very Important	Less Important
Catalyst Suppliers	Few	Many
Catalyst Management	Manage many layers	Keep or Change
Onsite Labor Force	Significant (50 to 300)	Minimal (< 20)
Catalyst Poisons	Many in fuel (arsenic)	Few/None
Operation	Consistent	Variable
CO Oxidation Catalyst	No	Yes

**Gas
CT**



Coal



Types of Catalyst Tests Used for SCR/CO Systems

How Much?

Performance Testing

Common for SCR:

- NO_x Removal Performance
- NH₃ Oxidation
- NH₃ Capacity
- SO₂ Oxidation

Special Testing

Common for Oxidation Catalyst

- CO Removal Efficiency
- VOC Removal Efficiency
- NO to NO₂ Oxidation
- SO₂ Oxidation
- Formaldehyde Removal Efficiency
- Special Testing

Why?

Chemical Analysis

Surface Techniques

- SEM
- EDS
- XPS/ESCA
- PIXE

Bulk Techniques

- ICP
- XRF
- Dispersion/Microprobe

Physical Analysis

Common – Field Samples


- Pore Volume
- Pore Size
- Pore Surface Area (BET)
- XRD

Special Tests - Manufacturing

- Mercury Porosimetry
- Abrasion Testing
- Washcoat Adhesion Testing
- Strength Testing

Performance Testing Techniques - Micro Scale vs. Full Block

- **Two common test scales used in industry for SCR**
 - Full block typically a 6" x 6" cross section, up to 40" length reactor
 - Bench Scale reactor uses small core samples – 1" to 3" cross section



Full Block/Bench

- Plant conditions are replicated in pilot scale
- Thermal stability takes longer to achieve
- Common for Coal
- Used in Gas



Semi-Bench/Lab Scale

- Small scale is more economical for testing multiple samples and test conditions
- Used in Coal
- Common for Gas


Full Block Testing

Pros:

- Sample trays can be used
- Sample can be reinstalled
- Meets VGB and EPRI guidelines

Cons:

- Fewer samples/\$
- Limited test range
- Sample repeatability




Lab Scale Testing – (Micro Testing)

Pros:

- Multiple samples
- Good repeatability
- Exact gas composition
- More Flexibility
- Less \$/sample
- Meets VGB and EPRI Testing Guidelines




Cons:

- Linear velocity can be different
- Experienced test operator required




Comparison of Full Block vs. Lab Scale

- Comparison between full block and lab scale activity results investigated
- Good correlation between test methods found for both honeycomb and plate-type catalyst



Performance Test Results – SCR Catalyst


Common Trends



GHSV = 40,000 hr⁻¹
2.7 mm pitch catalyst

- NOx Conversion increases with Ammonia-to-NOx (A/N) ratio
- NOx Conversion increases with Temperature to about 750°F
- Above 750 °F NOx Conversion Declines
- Catalyst Formulation can impact the temperature of peak performance



Performance Test Results – CO Catalyst









- CO oxidation “lights off” as temperature increases
- **Fouling** shifts the maximum potential CO oxidation downward
- **Poisoning/deactivation** increases the minimum temperature needed to achieve the design CO conversion

Catalyst Deactivation


SCR



CO



Fouling Blocks Mass Transfer




Poisoning Eliminates Active Sites

Physical Analysis Techniques


- **BET Surface Area Measurement**

- NO_x conversion proportional to surface area available for reaction when thermal damage or masking is the primary cause of performance loss



- **SEM Imaging**

- Used to examine the physical condition of the catalyst surface. Masking and fouling are often visible



- **XRD – Crystalline Phase Analysis**

- Used to determine presence and extent of thermal damage. Phase change from Anatase to Rutile Titania



Common Chemical Analysis Techniques


- **Surface Techniques**

- EDS (Energy Dispersive X-ray Spectroscopy)
 - Broad spectrum surface technique
 - Helpful in identifying surface contamination
- ESCA/XPS – Electron Spectroscopy for Chemical Analysis
 - Broad spectrum
 - Thin film analysis (20-30 Angstrom)

- **Bulk Techniques**

- ICP – Inductively Coupled Plasma Techniques
 - ICP-MS or AES used for quantitative analysis of bulk samples
- XRF – X-ray Fluorescence
 - Quantitative, broad spectrum bulk analysis technique


Chemical Analysis Techniques – Example EDS



Mass (%)



Al	1.11%
Si	2.23%
S	0.62%
Ca	0.41%
Ti	80.36%
V	3.34%
W	11.94%

Determining the Primary Cause of Performance Loss




Fouling from dust and insulation is the #1 cause of performance loss

Life Cycle Analysis from Catalyst Testing




Case Study – Spikes in Stack NOx at Reduced Load



Spikes in Stack NOx at Reduced Load


- Not related to Ammonia Flow
- Periodic and “unpredictable”
- Always below 70% Load
- Does occur during start but not always related to transition

Case Study – Exceptionally High Variation on “Good” Days




Extreme Variations in Ammonia Flow and Stack NOx



Case Study – Spikes Related to High NO₂




Case Study – Spikes Related to High NO₂




Case Study – Spikes Related to High NO2




SCR Catalyst Performance With High NO₂





CO Catalyst Impact on NO₂




The primary reaction across the CO catalyst is:



Secondary Reactions :




Using Performance Testing to Find/Test Solutions



VOC blend is 50% propane/50% butane

Can we reduce CO catalyst size to reduce how much NO2 is made?

Using Performance Testing to Find/Test Solutions



VOC blend is 50% propane/50% butane


Can we reduce the CO catalyst platinum loading to reduce how much NO₂ is made?

Platinum Migration from CO Catalyst to SCR




Washcoat Loss



Testing for Platinum Migration




The primary reaction across the CO catalyst is:



Secondary Reactions :



If the CO Catalyst Migrates to the SCR Catalyst



Thank You !!

Dan Ott

ott@environex.com

Visit us in the Exhibit Hall